



Old style ORP and pH sensors.

The exposed red sensor is an ORP sensor. This connector predates the connector to the right which includes a PVC sleeve and an o-ring sealed retainer nut.



Remove existing fittings for old style sensors



Remove old compression fitting



New Sensor Hardware

Install the new PVC sleeve into existing $\frac{3}{4}$ " tee.



New Sensor

Slide the new sensor into the sleeve and turn it clock-wise until tight.



New Cables

Connect the new style cables to the new sensor (s). Connect the open ended tinned leads into the controller as required.